




Assistance télévision avec récepteur

Écouter la télé

- 1- **Allumer** le **récepteur** satellite Shaw

Télécommande Shaw : Appuyer sur  puis .

Le voyant  devrait être allumé sur le récepteur Shaw.


- 2- **Allumer** la télé

Télécommande Shaw : Appuyer sur  puis .

Vérifier qu'il y a une image sur la télé.

- 3- **Télé** : vérifier derrière la télé **dans quelle entrée HDMI** le câble HDMI est branché

- 4- **Télé** : sélectionner l'entrée **HDMI** trouvée à l'étape précédente

Télécommande de la télé : Appuyer sur  et sélectionner l'entrée HDMI trouvée à l'étape précédente.

Brancher votre appareil sur la télé

- 1- **Débrancher** le câble **HDMI** derrière le récepteur Shaw.

- 2- Brancher le câble **HDMI** dans **votre appareil**, puis **l'allumer**.


- 3- **Allumer** la télé

Télécommande Shaw : Appuyer sur  puis .

Vérifier qu'il y a une image sur la télé.

- 4- **Télé** : vérifier derrière la télé **dans quelle entrée HDMI** le câble HDMI est branché

- 5- **Télé** : sélectionner l'entrée **HDMI** trouvée à l'étape précédente

Télécommande de la télé : Appuyer sur  et sélectionner l'entrée HDMI trouvée à l'étape précédente.

Y a-t-il des piles dans les télécommandes?

Pour des piles de télécommande, contacter le chef d'équipe : _____



UNIVERSITÉ
LAVAL


Service des résidences



Television with receiver Assistance


Watch TV

- 1- **Turn ON** the Shaw satellite **receiver**

Shaw remote: Press  and .


The indicator  should be lit the Shaw receiver.

- 2- **Turn ON** the **TV**

Shaw remote: Press  and .


Check that there is an image on the TV.

- 3- **TV**: Check behind the TV **in which HDMI input** the HDMI cable is plugged
- 4- **TV**: Select the **HDMI** input found at the previous step

TV remote: Press  and select the HDMI input found at the previous step.


Connect your device on the TV

- 1- **Unplug** the **HDMI** cable behind the Shaw receiver.
- 2- Plug the **HDMI** cable into your **device**, then **power it on**.
- 3- **Turn ON** the **TV**

Shaw remote: Press  and .

Check that there is an image on the TV.

- 4- **TV**: Check behind the TV **in which HDMI input** the HDMI cable is plugged
- 5- **TV**: Select the **HDMI** input found at the previous step

TV remote: Press  and select the HDMI input found at the previous step.

Are there batteries in the remotes?

For batteries in remotes, please contact the team leader: _____